Assembly Instructions | upCentric Dual Monitor Arms

Parts

A (x 1)	B (x 2)	C (x 2)	D (x 2)
Desk Clamp	Arm	VESA Bracket	180° Lockout Screw
			
E (x 8)	**F (x 3)**	**G (x 1)**	
Monitor Screw	Allen Wrench	Grommet Plate and Clamp Screw	
			

Installation instructions

<u>Base Installation – Clamp Style</u>

Step 1: Fit desk clamp (**part A**) over the edge of the desk in desired location and tighten using provided Allen wrench (**part F**) as shown in **Figure #1**.



<u>Base Installation – Grommet Style</u>

Step 1: Locate and mark installation site.

Step 2: Separate lower section of clamp by removing center bolt and set aside (**part G**).

Step 3: Install long bolt through base and desk top. Thread grommet plate over bolt and tighten with grommet nut as shown in **Figure #2**.



Assembly Instructions | upCentric Dual Monitor Arms

Arm Installation & 180° Lockout (Optional)

Step 1: Install arm onto base. Note upper and lower arm sections should be secured together using provided screw as shown in **Figure #3**.

Step 2 (optional): Make sure the lower arm part faces towards the forward direction.

Step 3 (optional): Tighten the screw (**part D**) in the front of the arm using the Allen wrench to initiate the 180° lockout function.



VESA Bracket / Monitor Installation

Step 1: Lay monitor on a flat surface. Using the provided monitor screws (**part E**) secure VESA bracket (**part C**) to the back of the monitor as shown in **Figure #4**.

Step 2: Install monitor onto arm. Align VESA bracket to opening and slide into place as shown in **Figure #5**.

Step 3: Accommodates PC monitors up to 32" and 19.8 lbs/kg.





Adjust Arm Tension



Step 1: In order to adjust the tension of the monitor arm according to the weight of the arm; the monitor arm must be lowered to a horizontal position as shown in **Figure #6**.

Step 2: Use the provided Allen wrench (**part F**) to adjust the arm's tension to hold your arm in the proper position. Rotate the wrench counter-clockwise (+) to tighten the arm for heavier monitors and rotate the wrench clockwise (-) to loosen the arm for lighter monitors.

Step 3: Using the Allen wrench provided to tighten the screws for heavier monitors.

Cable Management



Monitor cables may be threaded through the upper and lower sections in order to complete the installation.

Note: An allowance of extra cable should be left to accommodate arm movement.

If you need assistance:

Please contact ergoCentric:

- Phone : 1 866 GET ERGO (438-3746)
- Email : service@ergocentric.com